



Description: Projector headlight with CCFL
Part Number: 111115-111116
Application: Toyota FJ Cruiser 07-08



Tools Needed
8mm Socket and wrench
Phillips and Flat Screwdriver
Pliers

Remove the 4 screw that run along the top of the core support. 2 are for the grill and 2 are for the headlights.

Remove the push tabs located at top of the headlight.



Remove the two small screws located at the top of the headlight. (1 per side)

Gently remove the grill from the vehicle.

Remove the bolt from the bottom of the headlight.



Gently remove the corner piece from under the headlight by pulling outward. Remove the bolt located behind this piece.

Remove the headlamp and parking lamp assembly.

Remove the 3 8mm nuts that connect the headlamp and the parking lamp.

Reassembly your new
anzo light to the parking light



Plug the headlight into the stock
harness.
Reinstall the headlamp and parking
lamp assembly onto the vehicle by
reversing the steps. Be sure to
reuse all your OEM hardware.

Splice the red and black wire into
your parking light power and ground



Test all functions of the light

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.