



## INSTRUCTION SHEET

**Please read the following instructions carefully and thoroughly before installing your new manifold**

### **Model: Standard Flange Sideways Mounting Adapters #2694**

If the four mounting holes are not drilled in the manifold for adapter plates, you must use the following procedure: Using gasket supplied in this kit as a template, install gasket on manifold using studs to locate gasket. Scribe the four inner holes on manifold. Remove gasket, drill and tap four holes with #F drill bit and 5/16-18 N.C. thread tap. Clean manifold thoroughly before installing manifold and adapters on engine.

©2008 Edelbrock Corp.  
Catalog #2694

**Edelbrock Corporation • 2700 California St. • Torrance • CA 90503**  
**Tech Line: 800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

Brochure #63-2694  
Rev. 11/08 - AJ/mc



## INSTRUCTION SHEET

**Please read the following instructions carefully and thoroughly before installing your new manifold**

### **Model: Standard Flange Sideways Mounting Adapters #2694**

If the four mounting holes are not drilled in the manifold for adapter plates, you must use the following procedure: Using gasket supplied in this kit as a template, install gasket on manifold using studs to locate gasket. Scribe the four inner holes on manifold. Remove gasket, drill and tap four holes with #F drill bit and 5/16-18 N.C. thread tap. Clean manifold thoroughly before installing manifold and adapters on engine.

©2008 Edelbrock Corp.  
Catalog #2694

**Edelbrock Corporation • 2700 California St. • Torrance • CA 90503**  
**Tech Line: 800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

Brochure #63-2694  
Rev. 11/08 - AJ/mc



## INSTRUCTION SHEET

**Please read the following instructions carefully and thoroughly before installing your new manifold**

### **Model: Standard Flange Sideways Mounting Adapters #2694**

If the four mounting holes are not drilled in the manifold for adapter plates, you must use the following procedure: Using gasket supplied in this kit as a template, install gasket on manifold using studs to locate gasket. Scribe the four inner holes on manifold. Remove gasket, drill and tap four holes with #F drill bit and 5/16-18 N.C. thread tap. Clean manifold thoroughly before installing manifold and adapters on engine.

©2008 Edelbrock Corp.  
Catalog #2694

**Edelbrock Corporation • 2700 California St. • Torrance • CA 90503**  
**Tech Line: 800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

Brochure #63-2694  
Rev. 11/08 - AJ/mc