



FORD FLATHEAD INTAKE MANIFOLD GASKET KIT
1938-53 Ford Flathead V8 Engines
Part #7234
INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation may result in poor performance and engine or vehicle damage.

DESCRIPTION: This Intake Manifold Gasket Kit is for 1938-53 Ford Flatheads. Kit includes one intake manifold gasket.

INSTALLATION PROCEDURE - Before installing, make sure to thoroughly clean all mating surfaces prior to installation. When installing the intake manifold gasket, we recommend applying Edelbrock Gasgacinch, P/N 9300, to the block's mating surface. Allow Gasgacinch to air dry before attaching the intake manifold gasket. This will help hold the gasket in place when installing the manifold. Torque manifold to manufacturer's specifications starting in the center and working your way out in a crisscross pattern.

Part #7234
Rev. 07/23/13 - QT/mc

©2013 Edelbrock LLC
Brochure #63-7234



FORD FLATHEAD INTAKE MANIFOLD GASKET KIT
1938-53 Ford Flathead V8 Engines
Part #7234
INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation may result in poor performance and engine or vehicle damage.

DESCRIPTION: This Intake Manifold Gasket Kit is for 1938-53 Ford Flatheads. Kit includes one intake manifold gasket.

INSTALLATION PROCEDURE - Before installing, make sure to thoroughly clean all mating surfaces prior to installation. When installing the intake manifold gasket, we recommend applying Edelbrock Gasgacinch, P/N 9300, to the block's mating surface. Allow Gasgacinch to air dry before attaching the intake manifold gasket. This will help hold the gasket in place when installing the manifold. Torque manifold to manufacturer's specifications starting in the center and working your way out in a crisscross pattern.

Part #7234
Rev. 07/23/13 - QT/mc

©2013 Edelbrock LLC
Brochure #63-7234