

INSTALLATION INSTRUCTIONS

** Installation recommendation: JBA recommends in most case that the vehicle be taken to a reputable exhaust shop for installation.

40-1536

2006-11 Dodge Ram Quad Cab 5.7L HEMI Dual Tips in Bumper Cut Out

Recommended Tools:

pry bar
ratchet
15mm deep socket
channel lock pliers
spray lubricant or
penetrating oil

Parts List:

Intermediate pipe	1
Muffler	1
Y Pipe	1
Left side crossover pipe	1
Tail pipe with 4.5" Tip	2
3" Muffler hanger clamp	3
2.5" Exhaust clamp	2

TO START:

1. Remove and inventory JBA exhaust.

2. Disconnect negative battery cable and allow vehicle exhaust to cool.



3. With the vehicle raised and properly supported, using the 15mm socket and ratchet, loosen the clamp, at the rear of the muffler, that secures the tail pipe to the muffler.



4. Spray lubricant on the exhaust pipe behind the muffler.



5. Spray lubricant on all factory rubber isolators.



6. Remove the factory tail pipe hanger from rubber isolator.



7. Remove tail pipe from the rear of the vehicle.



8. Using the 15mm socket and ratchet, loosen the clamp that secures the muffler assembly to the resonator/intermediate pipe.



9. Remove muffler hangers from rubber isolators.



10. Remove factory muffler assembly.



11. Install muffler hanger clamp into rubber isolators near the rear of the factory muffler location.



12. Install intermediate pipe and secure with exhaust clamp.



13. Insert muffler into intermediate pipe. Place exhaust clamp with hanger at the front of the muffler. NOTE: Support the muffler temporarily, until the muffler hanger clamp is used.



14. Insert Y Pipe into rear of the muffler.



15. Install right tail pipe through the rear of the vehicle into the Y pipe. Repeat for left side tail pipe. Install clamps but do not tighten at this time.



16. Insert tip and hanger into rubber isolator at the rear of the vehicle, near the spare tire.



17. Position exhaust clamp over slip connection on tip. Repeat for Left side.

Check that both tips are center in the bumper openings and tighten all clamps.

Lower the vehicle and reattach the negative battery cable.

After installation and initial drive, it is recommended that all clamps be re-tightened.

NOTES:

- 1) It may be necessary to loosen and realign the spare tire for proper clearance.
- 2) All exhaust systems will expand about 1" rearward when exhaust temperatures start to rise.