



**6130HKR (Painted) & 6130-1HKR (Ceramic)
6130-3HKR (Darkside) & 6130-4HKR (Titanium)
SUPER COMPETITION FULL LENGTH HEADERS**

1965-69 Passenger, Wagons – (Full Size) includes Galaxy & Monterey (390-428)

Thank you for making HOOKER HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled HOOKER to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your hooker exhaust system.

NOTE: Will not fit convertible models.

NOTE: Will only fit 16 bolt F.E. cylinder heads with the top four exhaust bolt holes in line - Will not seal properly on heads with the end upper bolts lower than the center bolts.

WARNING! Breaking in an engine with ceramic-coated headers **WILL** result in damage to the coating and will **VOID** all warranties. Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. HOOKER recommends using a cast-iron exhaust manifold or an old header to break in new engines to avoid coating damage.

BEFORE STARTING

Your vehicle must be raised a minimum of 36 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure. **CAUTION!** YOUR CAR SHOULD NOT BE SUPPORTED ON A BUMPER JACK.

LEFT SIDE:

1. Disconnect the battery cable to prevent damage to the electrical system.
2. Unbolt the stock headpipes at the manifolds and remove from the car (both sides).
3. Remove the stock exhaust manifold. Disconnect the transmission linkages (between the frame and bellhousing), equalizer bar (if automatic), or clutch cross shaft (if stick).
4. Position the flange gasket on the head and start the bottom row or (furnished) bolts, with a flatwasher on each bolt.
5. Remove the top half of the L-3 tube. Starting from below, work the header up through the chassis into position and slip over the bottom row of bolts.
6. Work the L-3 tube into place, inserting the lower end into the swedged stub on the main body of the header and the flange piece over the bottom row of bolts.
7. Insert the allen head bolt through the clamp tube on the L-3 tube (main body of header) and start the matching nut. Handtighten only.
8. Tighten all header bolts evenly. Tighten the clamp tube bolt.
9. Reconnect the transmission linkages.

RIGHT SIDE:

1. Remove the stock exhaust manifold. Disconnect the steering idler arm from the frame and push (down) out of the way.
2. Start the lower row of (furnished) header bolts with a flatwasher on each bolt.
3. Starting from below, work the header up through the chassis and slip onto the lower row of bolts.

NOTE: For automatic transmissions, carefully bend the transmission lines away from the header for clearance.

4. With the header loose, replace the idler arm. If the starter bolts were loosened, tighten them. Reroute the starter cable as required for clearance of the header tubes.
5. Start the remaining header bolts. Tighten all bolts evenly.
6. If equipped with an automatic choke, remove the choke tubes from the stock exhaust manifold and install in the U-tube on the #4 pipe. Connect to the stock carburetor fittings.
7. To connect the collectors to the headpipes, purchase Hooker Reducer kit #11030HKR.
8. Connect the battery, start the engine, and check for leaks. Be sure all brake lines, fuel lines, transmission fluid lines, heater hoses, and electrical wires have sufficient clearance. Reroute, as necessary.
9. When finished, give your car a test drive, checking carefully for any new noises. After several days of driving, retighten all the bolts.

HOOKER TECHNICAL SUPPORT: 1-866-GOHOLLEY

LIMITATION OF LIABILITY – DISCLAIMER:

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOKKER makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

California vehicle code, sections 27156 AND 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. HOKKER Headers have not received an exemption from these code sections and are to legal for sale or use in California on vehicles originally equipped with catalytic converters, it is illegal, except for racing vehicles, which may never be driven upon a highway. To remove or otherwise render inoperative any emission control device on the regulated motor vehicles – check catalog listings to ensure proper application in the other 49 states, unless otherwise noted, HOKKER Headers are not legal for pollution-controlled motor vehicles, except for racing vehicles, which may never be used upon a highway and are not intended or applicable for highway use.

6130HKR

Date: 7-28-10